

Rinsing (Only to be carried out by a specialist)

According to our experience, a few weeks after installing MEDIAGON, many impurities and corrosion have already dissolved inside the water pipes. For this reason, we recommend rinsing the pipes to remove the heaviest deposits, as follows:

a) Draining the pipes

1. Fully close the main water shut-off valve (near the meter).
2. Open all the water taps in the basement, and then throughout the house; don't forget to remove the sieves and rubber seals (which you mustn't lose) so that the water can drain out.

Be careful not to flush the toilet.

3. Once all the water has drained from the basement, open the small drain tap near the meter (if there is one). Let the remaining water drain into a bucket and close the tap again.
4. Close all the taps in the house, except the cold water tap, which is open to the maximum, in the bathtub, at the highest point, taking care to close the drain of the bathtub, in order to keep the water flowing.

b) Rinsing the pipes

- I. Re-open the main valve by turning very quickly.
- II. If you have left the cold water tap in the bath open at the highest point in the house, turn on the hot water very quickly, then turn it back on to mixed water until there is no more coughing and the water comes out clear. Then observe the quality of the water... Drain and clean the area.
- III. Proceed in this way to all the water points in the house. (To avoid spraying, preferably attach a cloth to the tap), but always open the taps very quickly.

Rinse in the following order:

1. Bathtub – 2. Wash basins – 3. Kitchen – 4. Showers